

Deployment Instructions

1. Hook the stainless steel support bracket onto the top of the well casing/enclosure and rest the bracket against the side of the well/enclosure.



2. Secure the Well-mount Field Table in place using the two cinch straps around the well casing/enclosure. Insert the end of the strap into the backside of the buckle and push it through the buckle lever. Pull the strap to tighten it.



3. Once secure, lift the tabletop up until it snaps into place.



Removal Instructions

1. Slightly lift the tabletop to release the hinge.



2. Push the hinge in (labelled "push") on the underside of the tabletop and fold the tabletop down. **Be careful not to pinch your fingers.**



3. To release the straps, push down on the lever of the buckle and pull the strap through.

