

YSI 3074 CARRYING CASE

Using the provided removable foam inserts, the YSI 3074 hard sided carrying case can be configured to be used with Pro Series and 556 model instruments, and will accept 3059, 6850 and 5083 flow cells. This case will accommodate all Pro Series and 556 cable lengths.

The carrying case comes with four (4) 130 ml plastic buffer bottles and multiple storage pouches built into the case top.

In order to prevent contamination and/or moisture from entering the connectors' pin area the 3074 case's design allows the cable to remain attached to the instrument during storage, which will keep all electrical connections clean and dry.

To get the most out of your new 3074 carrying case review the information provided below:



Instrument spacer insert is installed in the bottom of this area when shipped. Remove for Model 556.

Flow cell spacer insert. Remove for 3059 and 5083 flow cells.

YSI Incorporated

Yellow Springs, Ohio 45387 USA • Phone 937-767-7241 • 800-765-4974 • Fax 937-767-9353



3074 case shown with Pro Plus instrument and 6850 flow cell. Instrument spacer and flow cell spacer installed. The cable is connected to the instrument and is wrapped on a 3062 Cable Management Kit.



3074 case shown with Pro Plus instrument and 3059 flow cell. Instrument spacer installed and flow cell spacer removed. The cable is connected to the instrument and is wrapped on a 3062 Cable Management Kit.



3074 case shown with 556 instrument and 3059 flow cell. Instrument spacer and flow cell spacer removed. The cable is connected to the instrument.



3074 case shown with 556 instrument and 5083 flow cell. Instrument spacer and flow cell spacer removed. The cable is connected to the instrument.

Cleaning and Storage

Moisture will not harm the 3074 but it is recommended that it be stored as dry as possible. After use, dry the inside of the case with a clean towel and/or let it air dry. Mild detergent can be used to clean the case both internally and externally.

YSI Incorporated

Yellow Springs, Ohio 45387 USA • Phone 937-767-7241 • 800-765-4974 • Fax 937-767-9353

